# KF04390 - Electronic safe, 10l capacity

If you want to reset the code :
1) press the red button on the back of the door, the yellow indicating light will flash,
2) at the time you can set any 3---8 digits personal code you want
3) and then press "B" for confirmation.

Red indicating light
Green indicating light   Yellow indicating light

Plastic panel

Knob

Emergency key lock cover   Key panel

Battery box

Reset button

Emergency key